

# Procedure with a USB memory

(Model : BD-HP25A)

**1. Write the updated software on a USB memory to prepare the version-upgrading USB memory.**

**2. Connect the set to the monitor with an HDMI cable. (Keep the HDMI cable connected until the version-upgrading has been completed.)**

**3. Using the “POWER” key (on the set itself or on the remote controller), turn on the power.**

**\* Do not turn on the power with the “EJECT” key.**

**4. Insert the upgrading USB memory into the USB port.**

**5. When the USB memory has been recognized**

**(“x” mark on the USB icon disappears and the USB recognition on-screen display appears),**

**Move from [Settings], [Software Update Settings], [Manual Update] to [USB Memory], and then press the “ENTER” or “ ” key.**

**6. Press “OK” on the USB recognition confirm screen.**

**7. The power turns on itself and the upgrading gets started.**

**LCD display: V-UP blinking → V-UP kept on**

**Mode display: Blue LED blinking → Blue LED kept on Monitor screen: Upgrading progress displayed**

**8. When the software has been 100% overwritten, the power turns off itself.**

**9. Draw the USB memory out of the USB port and press the “POWER” key to turn on the power again.**

**10. When the wallpaper shows up, hold down the “POWER” key to do the resetting. (Keep the “POWER” key depressed until the RESET message appears on the LCD. (About 10 seconds))**

**11. Press the “POWER” key again to turn on the power.**

**12. When the wallpaper shows up again, move from [Settings] to [Version] to make sure the software is upgraded.**

**13. When the upgrading has been successfully made, close the [Version] confirm screen and turn off the power. If it has failed, take the procedure over again from Step 3 above.**